



Press to turn on the Scout Flash. Press and hold to turn off.



Enter button - use to change settings or enter menus.





Up and Down buttons - adjust flash power and navigate menus.



Flash fire - use to test fire the flash.

If you are using multiple flashes at once - make certain each flash wireless ID is different. Press Enter then:

Settings → Wireless Settings → ID











Wireless ID = 1Channel = 15



Wireless ID = 2Channel = 15

Phone: 231-943-2425

Please let us know if you have any questions. We're glad to help!